


# NetGain Motors, Inc.

800 South State Street / Suite 4 / Lockport, IL 60441 / 630-243-9100 / 630-685-4054 (FAX)

## Brush wear indicators on **WarP** Motors



Circuit is completed when brush sensor wire 1 or 3 AND brush wear sensor 2 OR 4 make contact with the armature. Armature voltage will then be present at the connector.